SACHEN®

GAME PLAN

OPERATION INSTRUCTION

1. Connect the adaptor and any original Nintendo® game pak as shown on picture 1
2. Use attached connecting cable and connect its two ends to the sockets of both SACHEN® cartridge and adaptor.
3. Please insert SACHEN® cartridge into the control deck (label facing up) and push it all the way in
4. Turn on the power switch of the control deck and enjoy your SACHEN® exciting game.